



Troxler Electronic Laboratories, Inc.

PO Box 12057 • 3008 Cornwallis Rd. • Research Triangle Park, NC 27709

Tel: (919) 549-8661 • Fax: (919) 549-0761 • web: www.troxlerlabs.com

BATTERY LIFE RESET

- 1) From the “**READY**” screen, press **<SHIFT><SPECIAL>**.
- 2) Select Option **<1><2>**, “**BATTERY**”.
- 3) Select Option **<1>**, “**BATTERY MONITOR**”, then Option **<1>**, “**BATTERY LIFE**”.
- 4) Answer **<YES>** to the question: “Do you want to change hours?”, then input **<1><9><0>**, then press **<ENTER>**.
- 5) Again, from the “**READY**” screen, press **<SHIFT><SPECIAL>**.
- 6) Again, select Option **<1><2>**, “**BATTERY**”.
- 7) Again, select Option **<1>**, “**BATTERY MONITOR**”, but this time select Option **<2>**, “**BATTERY VOLTAGE**” and charge gauge. When the charger is plugged into the gauge, the screen should indicate “Battery Charging”.